




SURVEILLANCE PRO II MONITORING SYSTEM

Rackmaster Systems Announces Surveillance Pro II with SNMP

The newly designed Surveillance-Pro II monitoring system is the latest upgrade to our industry-leading Rackmaster Fault Resilient chassis. Surveillance Pro II continually monitors all internal system temperatures, cooling fans, and power supplies, and reports this information through a miniature web server using secure SSL to your internet browser at any remote location, notifies you through your SNMP compatible network monitoring system, or E-mails you automatically whenever a problem is detected.



Surveillance Pro II is completely independent of the computing systems components. Surveillance Pro II continually monitors activity as long as it has power. Even if your system is not operating, Surveillance Pro II will continue to provide information and E-mail you an alert informing you of a problem.

Three Ways to Monitor your Systems

From your Web Browser

Enter the Surveillance Pro II's IP address into any Internet browser, enter your user name and password, and information will be automatically and securely be displayed. Our customers use this feature to manage their Rackmaster chassis anywhere. Support personnel can obtain remote monitoring information from any computer with internet or network access.

With E-mail Alerts

Surveillance Pro II has the ability to send E-mail alerts automatically when an error is detected. Up to four E-mail addresses can be set up in each system alerting designated contacts of potential or critical issues.

Through Your SNMP Compatible Network Management System

Surveillance Pro II is able to report system status to any SNMP V1 compatible network management system.

Benefits of Surveillance Pro II

- Notification and alerts concerning the status of your system available anywhere and at any time.
- Receive notice of potential problems early.
- Simple to set up and easy to use.
- Completely independent of the computer system and its components. Surveillance Pro II is not dependant on the operation of the system.
- Increases system up-time, and availability.

(800) 480-4384

5244 Valley Industrial Boulevard South
Shakopee, MN 55379
www.rackmaster.com
(952) 233-9820
(952) 233-9815 fax

